

SWAGTRON®

USER MANUAL

Ver. 2.0 3/9/23

In order to continue serving our customers and providing the best products, our product information including our user manuals may receive updates from time to time. Please check our website for the latest user manuals and product materials.



EBIKE™
EB-6

Thank you for your purchase of the EB-6 eBike by SWAGTRON®!

There are many generic and copycat brands out there, but don't be fooled. If you want real swag, you're in the right place.

To ensure your safety and the safety of others, please read and be sure to follow all instructions and safety recommendations in this user manual prior to and when riding your bike.

If you have any questions regarding the SWAGTRON® EB-6 eBike, contact us at 1-844-299-0625 for further assistance.

Happy Riding!

-The SWAGTRON® Team

Table of Contents

PRODUCT SAFETY NOTICE	1
Section 1. General Information.....	3
1.1 About the SWAGTRON® EB-6 eBike.....	3
1.2 What's In the Box?	4
1.3 SWAGTRON® EB-6 eBike Diagram.....	5
Section 2. Assembling, Adjusting Your SWAGTRON® EB-6 eBike	6
2.1 Installing the Front Wheel.....	6
2.2 Adjusting Seat Height.....	7
2.3 Attaching the Pedals	7
Section 3. Charging Your SWAGTRON® EB-6 eBike.....	8
Section 4. How to Ride.....	10
Section 5. Safe Riding Techniques & Tips	11
5.1 Disposal at End-of-Life	12
Section 6. Maintenance	13
6.1 Cleaning	13
6.2 Storage.....	14
6.3 Transportation	14
Section 7. Specifications	15
1 Year Limited Hardware Warranty	16

PRODUCT SAFETY NOTICE

The SWAGTRON® EB-6 eBike has been designed with the utmost safety in mind for its riders. Extra precautions have been taken to protect the user from product hardware malfunctions through our meticulous design and engineering.

However, like any mode of transportation, the SWAGTRON® EB-6 eBike has inherent hazards associated with its use (e.g.: losing control, falling off, or riding into a hazardous situation). Be sure to read and follow all instructions and safety recommendations in this user manual prior to and when riding your eBike.

Before each ride, especially if you may travel a long distance, inspect your bike. First, check the tires for proper inflation and cracks on the walls of the tires. Keeping the tires properly inflated and maintained will help prevent flats and damage. Second, check all cables and cable housings for fraying, breaks, rust, or corrosion and replace if necessary. Lastly, inspect the brakes to make sure they are working properly. Additionally, check the brake pads for any damage as they will wear over time and eventually need replacement.

If a replacement of the brake pads or any other part is needed, please contact customer support for replacement service. In general, it is recommended to make sure all nuts and bolts are taut and properly fastened to prevent injury and unnecessary wear and tear on your eBike.

Maximum Weight	264 lbs / 120kg
Maximum Speed	18.6 MPH / 30 km/h
Max Incline	25° (throttle only)

This device requires coordination, agility, and balance. Use your best judgment to determine if an individual can use the SWAGTRON® EB-6 eBike safely.

SAFETY GEAR, CLOTHING, AND FOOTWEAR	<p>Please wear appropriate clothing and safety gear including shoes, kneepads, elbow pads and an ASTM F1492 approved helmet.</p> <p>Avoid wearing anything that can drape over or get caught into/under the wheels. Wear closed-toe, flat shoes to maintain flexibility and stability.</p>
MODIFICATIONS AND REPAIRS	<p>The SWAGTRON® EB-6 eBike is a highly sophisticated electronics product that includes complex, technical circuitry. Attempting to repair or modify your eBike can void all warranties. Only authorized repair centers may open and service the SWAGTRON® EB-6 eBike.</p>
OBEY LOCAL LAWS AND REGULATIONS	<p>Always check and adhere to local laws regarding personal transportation devices, including pedestrian laws.</p> <p>The eBike is considered a motor vehicle and should not be ridden after consuming alcohol or drugs.</p>

By riding the SWAGTRON® EB-6 eBike, the user acknowledges and accepts personal responsibility of all risks associated with the use of the SWAGTRON® EB-6 eBike, which may include, but are not limited to, muscle injuries, broken bones, lacerations, or serious injury that may be sustained while using the SWAGTRON® EB-6 eBike.

Section 1. General Information

This user manual will guide you through the functions and usage of your SWAGTRON® EB-6 eBike. Before operating this device, read all the instructions for safe assembly, charging, and usage.

Upon unpacking, please inspect the SWAGTRON® EB-6 eBike for any signs of physical damage or defects. Ensure that the SWAGTRON® EB-6 eBike is fully charged before using.

If you have questions, contact SWAGTRON® before you attempt to use or return your eBike.

1.1 About the SWAGTRON® EB-6 eBike


The EB-6 Electric Bike is a compact, zero-emissions, personal transportation device that feels like a bike but rides like a moped! It's environmentally-friendly and uses only the highest quality components and industry-leading safety features.

- Riding speeds up to 18.6 mph
- Rechargeable, portable, and reliable
- Eco-friendly with zero emissions




1.2 What's In the Box?

- 1 x SWAGTRON® EB-6 eBike
- 1 x Front Wheel
- 1 x Charging Cable & Adapter
- 2 x Pedals
- 2 x Keys
- 1 x Allen Key
- 1 x Wrench
- 1 x User Manual




SWAGTRON® EB-6 Electric Bike x 1




Front Wheel x 1



Charging Cable & Adapter x 1



Pedals x 2



Keys x 2



Allen Key x 1



Wrench x 1



User Manual x 1

1.3 SWAGTRON® EB-6 eBike Diagram



Section 2. Assembling, Adjusting Your SWAGTRON® EB-6 eBike

NOTE: Be careful not to position your fingers between the latch and the stem. Doing so may result in injury.

2.1 Installing the Front Wheel

For initial assembly, you will need to ask for someone's help.

Step 1. Have someone hold the front wheel upright on the floor (fig.1).

Step 2. Pick up your eBike, line up the fork with the axle at the center of the wheel, and fit the two together. (fig.1).

Step 3. On one side of the wheel, slide 1x black spacer on the axle then add 1x nut and tighten slightly (fig.2). Repeat on the other side of the axle with the other black spacer and nut. Use the included wrench to fully tighten each nut.



An extra spacer may have been included with your bike. If the front brake is difficult to adjust and/or use, add this spacer between the front fork and wheel on the left side (left side when seated on the bike). If this part was not included with your bike or you otherwise need a replacement, please contact customer service.




fig. 1




fig. 2

2.2 Adjusting Seat Height

For better pedaling, safety, and overall comfort, positioning the seat at the right height is key. The rider's leg length is used to determine the seat's position. During pedaling, your hips should remain level while your legs shouldn't suffer strain from over-extension. To determine the right seat height, sit on the eBike with one pedal at its lowest point and place the ball of your foot on the pedal. If your knee bends slightly at this position, the seat is at the right height. Additionally, when placing your heel on the pedal, your leg should be nearly straight.

First, open the clamp under the seat post. Pull the seat up or push it down to adjust height. Check to make sure the seat post is fully inserted into the frame and the head of the seat is parallel with the frame. Lastly, close the clamp to secure the seat in place (fig. 3).




fig. 3

2.3 Attaching the Pedals

Before installing the pedals, please check each for a small letter to indicate which side of the bike the pedal should be attached to. **L** is for the left side while **R** is for the right side (fig.4).




fig.4

With the kickstand holding your eBike upright, screw the pedals onto the crank arms (fig.5) and tighten them with the included wrench.




fig.5

Section 3. Charging Your SWAGTRON® EB-6 eBike

WARNING: Ensure the eBike is turned off before charging and remains off while charging.

- Step 1.** Connect the charging adapter and cable together then turn the rubber cap covering the charging port.
- Step 2.** Insert one end of the charging cable into the charging port and connect the other end to a wall outlet.
- Step 3.** Allow at least 5 hours when charging for the first time. After this initial charge, average charging time is 4–5 hours.
- Step 4.** While the eBike is charging, the adapter's indicator light will turn red.
- Step 5.** When the eBike is fully recharged, the adapter's indicator light will turn green. You may then disconnect the eBike from the charger.

How to Detach the Battery

For your convenience, the EB-6's battery can be removed for easier charging and/or an extra measure of security.

- Step 1.** Open the latch under the seat, remove the seat from the seat post and set it aside.
- Step 2.** Use the included keys to unlock the battery via the keyhole near the charging port (fig.7). To unlock the battery, insert the key, push it in, and turn it counterclockwise to the UNLOCK position.

NOTE: You must push the key in and turn it at the same time.




fig.6




fig.7

Step 3. Use the handle on top of the battery to pull it up and remove it (fig.8).

Step 4. Reinstall the battery, lock it, and replace the seat as needed. To lock the battery in place and/or turn it on or off, insert the key into the keyhole, then turn the key clockwise to the ON or OFF positions.

NOTE: To use the throttle, the battery must be ON. To turn it off when you will not use the battery, turn the key to the OFF position.

Safety tips for charging your battery:

- Fully charge the battery before your first use, this may take up to 5 hours.
- To maximize the life of the battery, you must charge it after each riding session.
- When not in active use, please charge at least once a month to maintain optimal battery levels.
- Perform periodic visual inspection of the battery ports and charging cables.

NOTE:

- When the battery is fully charged, please STOP CHARGING and unplug the unit.
- Keep your charging environment clean and dry at all times.
- If the charging port is damp or has any liquid on it, do not charge your eBike.
- In order for the battery to operate at maximum efficiency, avoid charging your eBike in extremely hot or extremely cold environments.
- Use only the battery and charging cable provided to you by SWAGTRON®, use of third party products may compromise the battery and damage the eBike. If a replacement is needed, please contact SWAGTRON® directly.

DO NOT charge the battery in the following cases:

- There is excessive odor or heat.
- Leakage or physical damage.




fig.8

Section 4. How to Ride

The instructions below will ensure you have a comfortable and safe riding experience. Please read carefully. Remember to use the keys to turn the battery into the ON position if you plan to use the throttle and/or battery power. **For regular pedaling without power and/or after you are done riding, use the keys to turn the battery OFF.**



- Start your eBike by pressing the Power Button, or ride it with your feet directly.
- Moving forward on your eBike is as easy as twisting the Throttle.
- Switch between 7 gears by pressing the Gear Button or pushing the Gear Switch.
- To stop, release the Throttle, then squeeze the front and rear brakes to slow the front and rear wheels down.
- Use the Bell to alert pedestrians and other riders of your presence.
- The Indicator shows how much charge is left in the battery. Make sure the battery is at full power before heading out on a long distance ride.

Section 5. Safe Riding Techniques & Tips

Following these techniques and tips can ensure you have a safe, fun riding experience on the EB-6 Electric Bike. Check to make sure your brakes are fully intact, pedals are securely installed, and seat is locked in place.

- Always wear an ASTM F1492 approved helmet and protective gear to avoid possible injury.
- Make sure your feet are always on the pedals. Taking your feet off the pedals while riding is dangerous.
- Ensure the battery is fully charged especially if you plan to travel long distances.
- Ensure your tires are intact with no punctures.
- Ensure the vehicle speed is safe to yourself and others, and be ready to stop at any time.
- When riding with friends, keep a safe distance from fellow riders to prevent collisions.
- Be aware of your surroundings at all times to ensure a safe ride. Your eyes are your best tools for safely avoiding obstacles and slippery surfaces.
- Stay in open spaces and flat areas. Avoid steep slopes or high-traffic areas until you're familiar and comfortable with riding the EB-6.
- Only ride the eBike where permitted. You **MUST** comply with local laws and give way to pedestrians.

WARNING:

- Never ride at high speeds, uneven terrain, or steep slopes.
- Never perform stunts or turn abruptly without checking your surroundings.
- Never carry passengers on the eBike with you.
- Never carry heavy items while riding.
- Never ride in the rain.
- Never use the eBike to do anything that may cause personal injury or property damage.
- Never get off the eBike when it is in motion.

FAILURE TO USE COMMON SENSE AND HEED THE ABOVE WARNINGS INCREASES THE RISK OF SERIOUS INJURY OR, IN VERY RARE CASES, DEATH. USE WITH APPROPRIATE CAUTION AND SERIOUS ATTENTION TO SAFE OPERATION.

For more safe riding tips or information, visit www.swagtron.com.

5.1 Disposal at End-of-Life

This product must not be disposed of by incineration, landfilling, or mixing with household trash. Improper disposal of the battery contained within this product may result in the battery heating up, rupturing, or igniting which may cause serious injury. The substances contained inside the battery present chemical risks to the environment. The recommended disposal for any SWAGTRON® product at its end-of-life is to dispose of the entire unit at or through an e-waste recycling center, program, or facility. Local regulations and laws pertaining to the recycling and disposal of lithium-ion batteries and/or products containing them will vary according to country, state, and local governments. You must check laws and regulations corresponding to where you live in order to properly dispose of the battery and/or unit. It is the user's responsibility to dispose of their waste equipment properly with accordance with local regulations and laws.

For additional information about where you should drop off your batteries and electrical or electronic waste, please contact your local or regional waste-management office, your household waste disposal service, or your point-of-sale.

Section 6. Maintenance

NOTE:

- Do not perform any kind of maintenance while the eBike is charging.
- Attempting to repair or modify your eBike can void all warranties. Only authorized repair centers may open and service the eBike.

If you need assistance, please contact SWAGTRON® support at support@swagtron.com.

6.1 Cleaning

Proper cleaning of your eBike can guarantee a longer lifespan and a smooth riding experience.

- Wipe the outer body of your eBike with a soft, dry microfiber cloth.
- Check around the wheels and ensure there is no blockage, the eBike's design allows for easy wheel maintenance.
- The eBike meets IPX4 water-resistance, meaning it can withstand splashes; however, do not submerge the eBike in water.
- Do not let water and liquids get into the eBike's electric parts or battery.

6.2 Storage

Below are some tips to consider when storing your SWAGTRON® EB-6 Electric Bike.

- Before storing, fully charge the eBike to prevent battery over-discharge due to non-use.
- If storing the eBike for more than one month, discharge and recharge the battery at least once a month.
- Cover the eBike to keep dust out. Do not store in a dusty environment as this may cause damage over time.


6.3 Transportation

Before moving, lifting, or otherwise transporting the eBike, turn it off. Grasp it firmly before lifting and/or moving it. Note, the eBike weighs approximately 48.5 lbs. If you are unsure of your ability to lift this much weight with one hand or arm, doing so is not recommended. Please lift the eBike with both arms or otherwise gain the assistance of someone who may handle the weight without trouble.

Lithium-ion batteries are considered hazardous materials; therefore, transportation is governed by federal, state, and local laws.

International law prohibits the shipping of bare lithium-ion batteries. If you are shipping your SWAGTRON® EB-6 Electric Bike, you must ship it with the battery installed.

Section 7. Specifications

Item	Parameters
Model Name	EB-6
Net Weight	48.5 lbs / 22 kg
Dimensions	67.3 x 22.5 x 37.8 in. / 1710 x 570 x 960 mm.
Max Incline	25°
Maximum Load	264 lbs / 120 kg
Battery	36V 7.8 Ah
Charging Voltage	110V - 220V / 50 - 60Hz / 42V 2A 
Wheel Size	23.6" Front / Rear
Wheel Inflation	20 PSI 1.4 BAR
Charging Time	4 ~ 5 Hours
Water Resistance	IPX4
Warranty	1 Year Limited

1 Year Limited Hardware Warranty

Your SWAGTRON® EB-6 Electric Bike ("Product") includes a One Year Limited Hardware Warranty ("Warranty"). The Warranty covers product defects in materials and workmanship under normal use. This Warranty is limited to residents of the United States and Canada only and is available only to original purchasers. This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

This Warranty starts on the date of your purchase and lasts for one year (the "Warranty Period"). The Warranty Period is not extended if the Product is repaired or replaced. We may change the availability of this limited warranty at our discretion, but any changes will not be retroactive.

Warranty services are provided by SWAGTRON®. If a hardware defect arises and a valid claim is received within the Warranty Period, at its option and to the extent permitted by law, SWAGTRON® will: (1) repair the hardware defect by using new or refurbished parts that are equivalent to new in performance and reliability; or (2) exchange the Product with a product that is new or refurbished which is substantially equivalent to the original product. This Warranty is for one replacement only of like-items and does not cover items out of production if the product is no longer made or stocked. This Warranty is not assignable or transferable. The original purchaser may call SWAGTRON's toll-free number at 1-844-299-0625 for service request.

When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes SWAGTRON®'s property. This warranty only covers technical hardware defectiveness during the warranty period and under normal use conditions. SWAGTRON® does not warrant uninterrupted or error-free operation of this Product.

This Warranty does not cover any damage due to: (a) transportation; (b) storage; (c) improper use; (d) failure to follow the product instructions or to perform any preventive maintenance; (e) modifications; (f) unauthorized repair; (g) normal wear and tear; or (h) external causes such as accidents, abuse, or other actions or events beyond our reasonable control.

Important: Do not disassemble the Product. Disassembling the Product will void this Warranty. Only SWAGTRON® or a party expressly authorized by SWAGTRON® should perform service on this Product.

DISCLAIMER OF WARRANTY: THE REMEDIES DESCRIBED ABOVE ARE YOUR SOLE AND EXCLUSIVE REMEDIES AND OUR ENTIRE LIABILITY FOR ANY BREACH OF THIS LIMITED WARRANTY. OUR LIABILITY SHALL UNDER NO CIRCUMSTANCES EXCEED THE ACTUAL AMOUNT PAID BY YOU FOR THE DEFECTIVE PRODUCT, NOR SHALL WE UNDER ANY CIRCUMSTANCES BE LIABLE FOR ANY CONSEQUENTIAL, INCIDENTAL, SPECIAL OR PUNITIVE DAMAGES OR LOSSES, WHETHER DIRECT OR INDIRECT.

SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

THE DURATION AND REMEDIES OF ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED TO THE DURATION OF THIS EXPRESS LIMITED WARRANTY.

SWAGTRON[®]

COPYRIGHT © 2023 SWAGTRON. ALL RIGHTS RESERVED.